





ART OF LIVING

## USER MANUAL

**DHG902**

**2C + 3G VITROCRAMIC HOB**



Customer Care Line: 086 100 DEFY (3339)  
Customer Care email: [service@defy.co.za](mailto:service@defy.co.za)

Part number: 3854820200 AD

**Cooking**  
Instruction manual

Dear Customer,

Your new Defy appliance was manufactured in a state of the art facility and has passed the strictest quality control procedures.

Important: Read these instructions for use carefully so as to familiarize yourself with the appliance before connecting it to its gas container. Keep these instructions for future reference.

This User Manual may also be applicable for several other models. Differences between models are explicitly identified in the manual.

This manual will provide you with information on how to operate and care for your appliance to gain the maximum benefit from it.

We trust you will enjoy years of trouble free use.

## EXPLANATION OF SYMBOLS

Throughout this User Manual the following symbols are used:



Important information or useful hints about usage.



Warning for hazardous situations with regard to life and property.



Warning for electric shock.



Warning for risk of fire.



Warning for hot surfaces.

**PLEASE REGISTER YOUR PRODUCT AT**

**[www.defy.co.za](http://www.defy.co.za)**

DEFY APPLIANCES (PTY) LTD

P.O.BOX 12004

JACOBS

DURBAN

4026

SOUTH AFRICA



**Important:** Read these instructions for use carefully so as to familiarize yourself with the appliance before connecting it to its gas container. Keep these instructions for future reference.

## Table of contents

---

<b><u>1 General information</u></b>	<b><u>4</u></b>	<b><u>4 Preparation</u></b>	<b><u>15</u></b>
Overview	4	Tips for energy saving	15
Technical specifications	5	Initial use	15
Package contents	5	First cleaning of the appliance	15
Injector table	5		
<b><u>2 Important safety instructions</u></b>	<b><u>6</u></b>	<b><u>5 How to use the hob</u></b>	<b><u>16</u></b>
General safety	6	General information about cooking	16
Safety for children	7	Using the hobs	16
Safety when working with gas	7	Fitting the burner cap	17
If you smell gas	8	How to use the electric plates	18
Intended use	8		
<b><u>3 Installation</u></b>	<b><u>9</u></b>	<b><u>6 Maintenance and care</u></b>	<b><u>18</u></b>
Before installation	9	Cleaning the hob	18
Aperture size	10	Gas jet cleaning procedure	19
Room ventilation	10		
Important information for the installer	10	<b><u>7 Troubleshooting</u></b>	<b><u>20</u></b>
Important information for the user	11		
Electrical connection	12	<b><u>8 Customer care</u></b>	<b><u>21</u></b>
Gas connection	12		
Leakage control	13	<b><u>9 Installer's Details</u></b>	<b><u>21</u></b>
Fitting the hob	13		
Final check	14	<b><u>10 Warranty</u></b>	<b><u>22</u></b>
Gas conversion	14		
Package information	15		
Future transportation	15		
Disposing of the old product	15		

Please register your product at  
[www.defy.co.za](http://www.defy.co.za)




# 1 General information

## Overview



- 1 Control panel
- 2 Vitroceramic glass

- 3 Pan supports



- 1 Cooking Plate Front left
- 2 Cooking Plate Rear left
- 3 Wok Burner

- 4 Rapid Burner
- 5 Semi-Rapid Burner



The manufacturer strives for continuous improvement. For this reason, technical specifications, text and illustrations in this manual are subject to change without notice. Figures are schematic and may not match your appliance exactly.

Technical specifications	
Voltage / frequency	220 – 240 V – 50Hz
Gas type Liquid Petroleum [IPG]/pressure	G30 /2.8 – 3kPa
Total Gas Consumption	8.2 kW
Converting the gas type Natural Gas [NG]/pressure	G20/2.0 kPa
External Dimensions [height/width/depth]	99mm / 890mm / 520 mm
Installation Dimensions [width/ depth]	803mm /470mm

Burner & plates	
Middle	Wok Burner
Power	3300W
Rear Left	200mm Vitroceramic Plate
Power	1700W
Front Left	165mm Vitroceramic Plate
Power	1200W
Rear Right	Rapid Burner
Power	2900W
Front Right	Semi-Rapid Burner
Power	2000W



Technical specifications may be changed without prior notice to improve the quality of the appliance.



Figures in this manual are schematic and may not exactly match your appliance.



Values stated on the appliance labels or in the documentation accompanying it are obtained in laboratory conditions in accordance with relevant standards. Depending on operational and environmental conditions of the appliance, these values may vary.

### Package contents



Accessories supplied can vary depending on the appliance model. Not every accessory described in the user manual may exist on your appliance.

### User manual

### Injector table


Position hob zone	2900 W Rear Right	2000 W Front Right	3300 W Middle
Gas type / Gas pressure			
G 20/2.0 kPa	115	103	140
G 30/2.8-3.0 kPa	87	72	96

## 2 Important safety instructions

This section contains safety instructions that will help you avoid risk of injury and damage. All warranties will become void if you do not follow these instructions.

### General safety

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Connect the appliance to an earthed outlet/line protected by a fuse of suitable capacity. Have the earth installation made by a qualified electrician. Our company shall not be liable for any problems arising due to the appliance not being earthed in accordance with the local regulations.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similar qualified persons in order to avoid a hazard.
- Do not operate the appliance if it is defective or has any visible damage.
- Do not carry out any repairs or modifications on the appliance. However, some issues may be remedied that do not require any repairs or modifications. See *Troubleshooting*.
- Never wash down the appliance with water! There is the risk of electric shock!
- Never use the appliance when your judgment or coordination is impaired by the use of alcohol and/or drugs.
- The appliance must be disconnected from the mains during installation, maintenance, cleaning and repair procedures.
- Be careful when using alcoholic drinks in your dishes. Alcohol evaporates at high temperatures and may cause a fire since it can ignite when it comes into contact with hot surfaces.
- Do not use the appliance for heating closed tins and glass jars. The pressure that would build up in the tin/jar may cause it to burst.
- Keep all ventilation slots clear of obstructions.
- Do not place any flammable materials close to the appliance as the sides may become hot during use.
- The appliance may be hot when it is in use. Never touch the hot burner, inner sections of the oven, heaters etc.
- Make sure that the function knobs are switched off after every use.
- When using Gas, ensure that the room is well ventilated.
- Ventilation is vital for the efficient performance of all appliances and for the safety of the occupants of the room in which the appliance is installed.
- Always keep children and infirm persons away from the appliance when it is in use.
- Only use the appliance for preparing food.
- Use a deep pan, large enough to cover the appropriate burner or hotplate.
- Always dry food thoroughly before placing it in hot oil or fat. Frozen food in particular will spit and splatter if added too quickly.
- Never fill the pan more than one third full of fat or oil.
- Never heat fat or fry with a lid on the pan.
- Do not fry too much food at once. This lowers the temperature of the oil or fat and results in fatty foods.
- Do not leave hot fat or oil unattended. If overheating occurs, these could catch fire.
- Do not use or store inflammable products (alcohol, petrol, benzene etc.) near the hob as these pose a fire risk.
- **WARNING:** If the surface is cracked, switch off the appliance to avoid the possibility of electric shock.
- Sealing washers should be correctly located and tested in accordance with the manufacturer's instructions.
- The hot surface indicator light – above the word “HOT” on the left of the knob - will activate to alert the user when the plate is turned on to a point where the glass surface has reached a temperature that may cause injury. The light will switch off when the surface has reached a safe temperature.”



### Safety for children

- Electrical and/or gas appliances are dangerous to children. Keep children away from the appliance when it is operating and do not allow them to play with the appliance.
- Accessible parts of the hob will become hot whilst the appliance is in use. Children should be kept away until the appliance has cooled down.
- Do not place any items above the appliance that children may reach for.
- The packaging materials will be dangerous for children. Keep the packaging materials away from children. Please ensure that the packaging material is disposed of in a responsible manner.

### Safety when working with gas

- Any work carried out on gas equipment and systems may only be done by authorised qualified persons who are **registered LP Gas installers**.
- Prior to installation, ensure that the local distribution conditions (nature of the gas and gas pressure) and the adjustment of the appliance are compatible.
- This appliance shall be installed and connected in accordance with current installation regulations. Particular attention shall be given to the relevant requirements regarding ventilation; See "*Before installation*".
- **CAUTION:** The use of gas cooking appliances results in the production of heat and moisture in the room in which it is installed. Ensure that the kitchen is well ventilated: keep natural ventilation holes open or install a mechanical ventilation device (mechanical extractor hood). Prolonged intensive use of the appliance may call for additional ventilation, for example increasing the level of the mechanical ventilation where present.



### **DANGER. Risk of explosion and poisoning!**

Put out all naked flames and do not smoke, strike matches or do anything that could cause ignition. Do not operate any electric switches (e.g. light switch, TV, computer, cooker or door bell). Do not use a telephone or mobile phone.

- Gas appliances and systems must be regularly checked for proper functioning. The regulator, hose and its clamp must be checked regularly and replaced within the periods recommended by its manufacturer or when necessary.
- Clean the gas burner regularly. The flames should be blue and burn evenly.
- Good combustion is required in gas appliances. In case of incomplete combustion, carbon monoxide (CO) might develop. Carbon monoxide is a colourless, odourless and very toxic gas, which has a lethal effect even in very small doses.
- Request information about gas emergency telephone numbers and safety measures from your local gas provider in case of a gas smell .

### **In the event of a pan fire**

- Switch off the Gas supply.
- Smother the flames with a blanket or damp cloth.
- Burns and injuries are usually caused by picking up the burning pan and rushing outside with it.
- **Do NOT use water to extinguish an oil or fat fire.**

### **SAVE THESE INSTRUCTIONS**

### If you smell gas

- Turn off all valves on gas appliances and gas meter at the main control valve, unless it's in a confined space or cellar.
- Extinguish all naked flames.
- Do not operate any electrical appliances.
- Ventilate the area. Open doors and windows.
- Check for leaks. Check all tubes and connections for tightness.
- If odour persists contact your nearest Defy Service Centre for assistance.
- If you still smell gas leave the property.
- Warn the neighbors.
- Call the fire-brigade. Use a telephone outside the house.
- If you have door or gates that are secured by an electric lock, or entry phone, please open these manually.
- Do not re-enter the property until you are told it is safe to do so.

### Action to be taken in the event of a burn back

- In the event of a burn back (where the flame burns back into the jet ) immediately turn off the control to the affected burner.
- Wait a few minutes and relight the burner in the normal manner.
- If the burn back occurs again, turn off the control knob to the affected burner, and consult the nearest Defy service technician, who will advise you.

### Ventilation

- Room ventilation is vital for the efficient performance of the appliance and for the safety of the occupants in the room in which the appliance is installed.

### Intended use

This appliance is designed for domestic use. Commercial use will void the warrantee.

**CAUTION:** This appliance is for cooking purposes only. It must not be used for other purposes.

This appliance should not be used for warming plates under the grill, drying towels, dish cloths etc. by hanging them on the oven door handles. This product should also not be used for room heating purposes.

The manufacturer shall not be liable for any damage caused by improper use or handling errors.

### Safety when working with electricity

Defective electric equipment is one of the major causes of house fires.

- Any work on electrical equipment and systems should only be carried out by authorized and qualified persons.
- In case of any damage, switch off the appliance and disconnect it from the mains. To do this, turn off the fuse at home.
- Ensure that the fuse rating is compatible with the appliance.



#### IMPORTANT:

If the gas type of the appliance is changed, then the rating plate that shows the gas type of the unit must also be changed.



#### IMPORTANT:

If the gas type of the appliance is changed, then the sticker that is currently on the underside of the appliance that reads “**LPG 2,8 kPa**” must be covered by sticking the sticker “**NG 2,0 kPa**” over it.



The new sticker can be purchased when buying natural gas injectors from your nearest Defy Service Center.



### 3 Installation


The manufacturer accepts no liability for installation. Any action that the manufacturer has to take as a result of an erroneous installation will not be covered by the warranty. Installation, including gas and electrical connections, must be carried out by qualified personnel. An installation by an unqualified person may constitute a hazard.

The manufacturer shall not be held responsible for injury to persons or damages arising from procedures carried out by unauthorized persons or due to non compliance with these provisions.

	Installation, preparation of location and electrical and gas installation for the appliance falls under the customer's responsibility.
	<b>DANGER</b> The appliance must be installed in accordance with all local gas and/or electrical regulations.
	<b>DANGER</b> Prior to installation, visually check if the appliance has any defects on it. If so, do not have it installed. Damaged appliances are a safety risk.

#### Safety installation

- A removable horizontal board must be fitted below the hob and 75mm away from the worktop bottom face.
- Space between this board and the appliance must be empty and no objects may be stored or kept there.
- This board will effectively shield the user from the base of the hob which gets hot during use. The board needs to be removable for service purposes as the hob, once installed, can only be loosened from below.
- If the appliance is installed with a side adjacent to a vertical kitchen cabinet, the distance between the edge of the appliance and that of the cabinet side must be at least 150mm. The distance between the back wall and the rear edge of the hob must be at least 55mm.



1 Minimum of 50 mm

#### Before installation


This appliance is designed for installation in a domestic worktop. A safety distance must be left between the appliance and the kitchen walls and furniture. See figure overleaf (values in mm).

- This appliance can also be used in a free standing position. Allow a minimum distance of 750 mm above the hob surface.
- (\*) If a cooker hood is to be installed above the appliance, refer to the cooker hood manufacturers instructions regarding installation height (min 650 mm)
- Remove packaging materials and transport locks.
- Surfaces, synthetic laminates and adhesives used must be heat resistant (100 °C minimum).
- The worktop must be aligned and fixed horizontally.
- Cut the aperture for the hob in the worktop as per installation dimensions.

This appliance uses LPG (Liquid petroleum or bottle gas) This appliance requires an operating pressure of 2.8-3.0 kPa. A suitable LPG regulator that complies with the requirements of SANS 1237 must be used. The manufacturer and the seller do not accept responsibility for any damage due to incorrect installation or gas connection.

- Gas bottles should be located outdoors in a suitable ventilated lock-up.
- The connecting hose should not exceed 200 cm in length.
- An appliance without a flame failure device may only be used with a free standing cylinder placed adjacent to but not closer than 300 mm to the appliance.

## Aperture size



### Room ventilation

All rooms require a window that can be opened, or equivalent, and some rooms will require a permanent vent in addition.

Air for combustion is drawn from the room and the exhaust gases are emitted directly into the room, therefore good room ventilation is essential for the safe operation of your appliance. If there is no window or door available for room ventilation, extra ventilation must be installed.

The appliance may be located in a kitchen, kitchen/diner or a bed-sitting room, but not in a room containing a bath or shower. The appliance must not be installed in a bed-sitting room of less than 20m<sup>3</sup>.

Do not install this appliance in a room below ground level unless it is open to ground level on at least one side.

Room size	Ventilation opening
Smaller than 5 m <sup>3</sup>	min. 100 cm <sup>2</sup>
5 m <sup>3</sup> to 10 m <sup>3</sup>	min. 50 cm <sup>2</sup>
Greater than 10 m <sup>3</sup>	not required
In the cellar or basement	min. 65 cm <sup>2</sup>

### Important information for the installer

This appliance may only be installed by a registered LP Gas installer registered with the LPGASA. (Liquefied Petroleum Gas Association of Southern Africa).

The appliance must be installed in accordance with the requirements of SANS 10087-1 or SANS 827 and any fire department regulations and/or local bylaws applicable to the area. If in doubt check with the relevant authority before undertaking the installation.

Upon completion of the installation you are required to fully explain and demonstrate to the user the operational details and safety practices applicable to the appliance and the installation including:

- The position of the isolation or shut-off valve in the gas supply line to the appliance.
- The requirements for safe operation of the appliance.

### Cupboard design

Cooking appliances generate considerable heat. The layout and materials of the mounting cabinet should take account of these characteristics.

Surfaces and surrounding edges immediately adjacent to the hob should be able to withstand temperatures of up to 100° C without delaminating or discolouring.

**Note.** This appliance is supplied ex-factory with jets and air settings for use with LP gas only.

**Safety compliance with local requirements.**

**Installer's details are to be filled in on page 21 of this book**

### **Temporary installation**

Flexible hose connection from the gas appliance to the bottle can be made. Ensure that pipe clamps are tightened correctly and are of good quality.

- **Flexible hose** - Not supplied.  
Any hose that is used to connect the stove to the gas system shall comply with SANS 1156-2 or BS 3212.
- **Gas bottle** - Not supplied.  
For best results we recommend that gas cylinders with a minimum capacity of 19kg be used.
- **Regulator** - Not supplied.  
A 2.8-3.0 kPa LP gas regulator which complies with SANS 1237 must be used.

### **Permanent installation**

#### **Important information for the user**

**This appliance may only be installed by a registered LP Gas installer. All registered installers are issued with a card carrying their registration number.**

**Ask to be shown this card before allowing the installation to commence and make a note of the installer QCC number on page 21 of this book.**

Upon completion of the installation, the installer is required to explain the operational details of the appliance together with the safety instructions. You will be asked to sign acceptance of the installation and be provided with a completion certificate. You should only sign for acceptance when the installation is completed to your satisfaction.

**Failure to comply with the above will render the warranty invalid.**



#### **Note:**



**Your invoice is required in the event of you wishing to make a warranty claim.**

## Electrical connection



Connect the appliance to a grounded outlet/line protected by a fuse of suitable capacity as stated in the "Technical specifications" table. Have the grounding installation made by a qualified electrician while using the product with or without a transformer.


The manufacturer shall not be held responsible for damages arising from procedures carried out by unauthorized persons.

 	<b>DANGER Risk of electric shock, short circuit or fire by unprofessional installation!</b> The appliance may be connected to the mains supply only by an authorized qualified person and the appliance is only guaranteed after correct installation.
--	---


 	<b>DANGER Risk of electric shock, short circuit or fire by damage of the mains lead!</b> The mains lead must not be clamped, bent or trapped or come into contact with hot parts of the appliance. If the mains lead is damaged, it must be replaced by a qualified electrician.
--	---

- Connection must comply with national regulations.
- The mains supply data must correspond to the data specified on the type label of the appliance. Type label is at the rear housing of the appliance.
- Power cable of your product must comply with the values in "Technical specifications" table.


 	<b>DANGER Risk of electric shock!</b> Before starting any work on the electrical installation, please disconnect the appliance from the mains supply.
--	---

	The power cable plug must be within easy reach after installation (do not route it above the hob).
---	--

## Gas connection


	<b>DANGER Risk of explosion or poisoning by unprofessional installation.</b> The appliance may be connected to the gas distribution system only by a registered LPG installer.
	<b>DANGER Risk of explosion!</b> Before starting any work on the gas installation, please shut off the gas supply.


- Gas adjustment conditions and values are stated on labels (or on type label).

	Your appliance is adjusted for LP gas.
---	--


### Connecting the gas hose

- Have your appliance connected so that it will be close to the gas connection. Ensure that there is no gas leakage.
- Gas bottles should be located outdoors in a suitable ventilated lock-up.
- The connecting hose to be used must not be longer than 200 cm in length.
- Install the clamp to the hose. Soak one end of the hose (15 mm inner diameter) into hot water for one minute to soften it. Then, slip the softened end of the hose completely onto the sharp hose tip of your appliance.
- Secure the hose by tightening the hose clamp
- Repeat the same procedure for the other end of the hose by securing the other end of the hose to the regulator on the gas bottle to complete the gas cylinder connection.
- Always check for gas leaks after installation and whenever a new or refilled gas bottle is used for the first time.


	<b>DANGER Risk of explosion and suffocation!</b> The maximum bottle size allowed in the house is 19 Kg. (Flat—9 Kg)
---	---

	<b>Caution:</b> Never use a naked flame to check for gas leaks
---	--

In case of power failure manually ignite the burner using an ignitor gun.



- 1 LPG hose tip  
2 Plastic hose



### Manifold protector plug removal:

The manifold protection plug is inserted into the manifold at factory level in order to protect the manifold from being contaminated with debris. The manifold protection plug must be removed when the product is installed by the gas installer. The red manifold protection plug can be removed from the manifold by grabbing it with your fingers or if necessary with the aid of a small pair of pliers.

### Leakage control at the connection point

- Ensure that the control knobs on the hob are in the OFF position.
- Open the valve on the Gas bottle.
- Using a small paint brush, apply some soapy water to all the connections.
- If there is a leak, bubbles will appear.
- If this happens, close the valve on the gas bottle.
- Check and tighten the connections immediately.
- Repeat the procedure to ensure that there are no further leaks.

### Installing the appliance


1. Remove burner, burner cap and grill on the hob from the appliance.
2. Turning the hob upside down, place it on a flat surface.

3. In order to avoid foreign substances and liquids penetrating between the hob and the counter, please apply the seal supplied in the package on the contours of the lower housing of the hob, making sure that the seal does not overlap.
4. Apply the seal by bending it around the corners as in the figure.




**i** Make sure the seal is filled on the base cover contours.

5. Turning the hob again, align and place it on the counter.
6. Secure your hob to the counter by using the clamp and the screws supplied. (wooden spacers may be required).



- \* min. 20 & max. 40 mm
- 1 Hob  
2 Screw  
3 Installation clamp  
4 Counter  
5 Seal

### Rear view (connection holes)





Place the burner plates, burner plate caps and grills back to their seating after installation.



Making connections to different holes is not a good practice in terms of safety since it can damage the gas and electrical system.

### Final check

1. Open gas supply.
2. Check gas installations for secure fitting and tightness.
3. Ignite burners and check appearance of the flame.



The flames should be blue and burn smoothly. If the flames appear yellowish, check that the burner cap is seated correctly or clean the burner. Switch off the gas and let burner cool before touching it.

### Gas conversion



**DANGER Risk of explosion or poisoning by unprofessional installation.** Gas conversion must only be carried out by a registered installer.


**DANGER Risk of explosion!** Before starting any work on the gas installation, shut off the gas supply.

In order to have the appliance's gas type changed, all the injectors must be changed and the flame adjustment for all valves must be set at the reduced flow rate position.

### Changing the injectors

1. Take off burner cap and burner body.
2. Unscrew injectors by turning them counterclockwise.
3. Fit new injectors.
4. Check all connections for secure fitting and tightness.

- 1 Flame failure device (model dependent)
- 2 Spark plug
- 3 Injector
- 4 Burner




Unless there is an abnormal condition, do not attempt to remove the gas burner taps. You must call an authorised service agent if it is necessary to change the taps.

New injectors have their position marked on their packing or refer to the Injector table.

### Reduced gas flow rate setting for taps

1. Ignite the burner that is to be adjusted and turn the knob to the reduced position.
2. Remove the knob from the gas tap.
3. Use an appropriately sized screwdriver to adjust the flow rate adjustment screw. For LPG (Butane - Propane) turn the screw clockwise. For natural gas, you should turn the screw **counter-clockwise** once. The normal length of a straight flame in the reduced position should be 6-7 mm
4. If the flame is higher than the desired position, turn the screw clockwise. If it is smaller turn anticlockwise.
5. For the last control, bring the burner to both the high-flame and reduced positions and check whether the flame is on or off. Depending on the type of gas tap used in your appliance the adjustment screw position may vary.



- 1 Flow rate adjustment screw



If the gas type of the appliance is changed, then the rating plate that shows the gas type of the unit must also be changed.

**IMPORTANT:**

If the gas type of the appliance is changed, then the sticker that is currently on the underside of the appliance that reads “**LPG 2,8 kPa**” must be covered by sticking the sticker “**NG 2,0 kPa**” over it. The new sticker can be purchased when buying natural gas injectors from your nearest Defy Service Center.

**Package information**

Packaging materials are dangerous to children. Keep packaging materials in a safe place out of reach of children.

Packaging materials of the appliance are manufactured from recyclable materials.

Do not dispose of the packaging materials together with domestic or other wastes. Dispose of them in a responsible manner.

**Future Transportation**

Keep the appliances original carton and transport the appliance in it. Follow the instructions on the carton. If you do not have the original carton, pack the appliance in bubble wrap or thick cardboard and tape it securely.

Secure the caps and pan supports with adhesive tape.

**Disposing of the old product**

Dispose of the old appliance in an environmentally friendly manner.

Refer to your local dealer or solid waste collection centre in your area to learn how to dispose of your appliance.

Before disposing of the appliance, cut off the power cable plug and make the door lock (if any) unusable to avoid dangerous conditions to children.



Check the general appearance of your appliance for any damages that might have occurred during transportation.

## 4 Preparation

**Tips for energy saving**

The following information will help you to use your appliance in an ecological way, and to save energy:

- Defrost frozen dishes before cooking them.
- Use pots/pans with cover for cooking. If there is no cover, energy consumption may increase up to 4 times.
- Select the burner which is most suitable for the bottom size of the pot to be used. Always select the correct pot size for your dishes. Larger pots require more energy.



This product is equipped with Precise flame which gives 9 specifically defined power levels. This allows for the flame size and heat to be adjusted with ease and reliability giving better defined and more controlled cooking results.

**Initial use****First cleaning of the appliance**

The surface may get damaged by some detergents or cleaning materials. Do not use aggressive detergents, cleaning powder/cream or any sharp objects.



1. Remove all packaging materials.
2. Wipe the surfaces of the appliance with a damp cloth or sponge and dry with a cloth.



In the unlikely event of your hob sustaining accidental damage or cracks, switch off the appliance at the mains immediately to avoid electric shock and have the panel replaced before further use.

## 5 How to use the hob


### General information about cooking

	<b>DANGER</b> <b>Risk of fire by overheated oil!</b> When you heat oil, do not leave it unattended.
	<b>Never try to extinguish a fire with water!</b> When oil has caught fire, immediately cover the pot or pan with a lid. Switch off the hob if safe to do so and phone the fire service.


- Before frying foods, always dry them well and gently place into the hot oil. Ensure complete thawing of frozen foods before frying.
- Do not cover the pot or pan you use when heating oil.
- Place the pans and saucepans in a manner so that their handles are not over the hob to prevent heating of the handles. Do not place unbalanced and easily tilting cooking vessels on the hob.
- Do not place empty pots and saucepans on cooking zones that are switched on. They might get damaged.
- Operating a cooking zone without a pot, pan or saucepan on it will cause damage to the appliance. Turn off the cooking zones after cooking is complete.
- As the surface of the appliance can be hot, do not place plastic and aluminum vessels on it.
- Such vessels should not be used to keep foods in either.
- Use flat bottomed saucepans or cooking vessels only.
- Put only the appropriate amount of food in saucepans and pans. Doing so will assist in you not having to do any unnecessary cleaning as this will help prevent the dishes from overflowing.
- Do not put covers of saucepans or pans on the cooking zones.
- Place saucepans so that they are centered on the cooking zone. When moving the saucepan onto another cooking zone, lift and place it onto the cooking zone you want instead of sliding it.

### Gas cooking

- The size of the cooking vessel and the flame must be suited to each other. Adjust the gas flames so that they do not extend past the bottom of the cooking vessel and ensure that the cooking vessel is centered on the saucepan carrier.



### Using the hobs






List of advised diameter of pots to be used on related burner or cooking plate.

- 1 Cooking plate rear left 18-20 cm
- 2 Cooking plate front left 14-16 cm
- 3 Wok burner 22-30 cm
- 4 Rapid burner 14-20 cm
- 5 Semi rapid burner 14-20 cm

### Igniting the gas burner



-  Maximum setting
-  Minimum setting
-  Off: Fully closed

The large flame symbol indicates the highest cooking power and the small flame symbol indicates the lowest cooking power. In the turned off position (top), gas is not supplied to the burners.




- Push the knob inwards and turn it counter clockwise to ignite.
- After the gas ignites, keep the knob pressed for 3-5 seconds more to engage the safety system.
- If the gas does not ignite after you press and release the knob, repeat the same procedure by keeping the knob pressed in for 15 seconds.

### Turning off the gas burner

Turn the keep warm zone knob to off (upper) position.

### Gas shut off safety system (in models with thermic component)



1. Gas shut off safety

As a counter measure against blow out due to fluid overflows at burner or should the flame extinguish for whatever reason, the flow of gas to the burner will automatically be terminated.

	<p><b>DANGER Risk of deflagration incase of unburned gas!</b></p> <p>Do not press the knob for longer than 15 seconds if there was no ignition. Wait for one minute and then repeat the ignition process.</p>
--	---

### Wok burner




Wok burners help you to cook faster. Wok, which is particularly used in Asian kitchens, is a kind of deep and flat fry-pan made of sheet metal. These are used to cook minced vegetables and meat in a short time using a strong flame.

Since meals are cooked using a strong flame and in a very short time, and as such fry-pans conduct heat rapidly and evenly, the nutritional value of the food is preserved and vegetables remain crispy. The wok burner can be used for regular saucepans too.

### Fitting the burner cap

- Carefully align the hole in the burner body with the flame failure sensor.
- Gently lower the burner body into position.
- Centralise and level the burner cap onto the burner body. (The burner cap must be positioned so that it rests centrally on the burner body). Ensure that it is correctly seated. Refit the pot stands.



	<p>Wrong centralizing of the burner cap may result in a flash back and cause burner to melt and deform. (After cleaning the burner cap ensure the cap is properly located on to the flame spreaders. See fitting burner cap).</p>
	<p>Wrong control of the gas valves: Gas valves must be controlled from 90° to 210° (or 160° according to the gas valve model) If flame is set from 0° to 90° the burner will be below the minimum output and may result in a flash back and cause burner to melt and deform.</p>
	<p>The above user faults are not covered by the warranty.</p>

### How to use the electric plates

The hob control knobs are used for operating the plates. To obtain the desired cooking power, turn the hob control knobs to the corresponding level.

Cooking level	1	2 — 3	4 — 6
	warming	stewing, simmering	cooking, roasting, boiling

### Turning off the ceramic plates



Turn the plate knob to OFF (upper) position.

## 6 Maintenance and care

### General information

The service life of the appliance will extend and problems will decrease if the appliance is cleaned at regular intervals.

- Cleaning of the valves must only be carried out by a qualified Defy technician. i.e. Burner not functioning correctly.
- The condition of the gas hose and valve must be inspected for leaks every time the gas bottle is re-filled.

	<b>DANGER Risk of electric shock!</b> Switch off the electricity before cleaning the appliance to avoid an electric shock.
	<b>DANGER Hot surfaces may cause burns!</b> Allow the appliance to cool down before you clean it.

- Clean the appliance thoroughly after each use. In this way it will be easier to remove cooking residues and prevent these from burning during next use.
- No special cleaning agents are required for cleaning the appliance. Use warm water with washing liquid, a soft cloth or sponge to clean the product and wipe it with a dry cloth.
- Always ensure any excess liquid is thoroughly wiped off after cleaning and any spillage is immediately wiped dry.
- Do not use cleaning agents that contain acid or chloride to clean the stainless or inox surfaces and the handle. Use a soft cloth with a liquid detergent (not abrasive) to wipe those parts clean, paying attention to sweep in one direction.



The surface may get damaged by some detergents or cleaning materials. Do not use aggressive detergents, cleaning powder/cream or any sharp objects.

Do not use steam cleaners or a water jet for cleaning.

### Cleaning the hob: Gas hobs

1. Remove and clean the saucepan carrier and burner cap.
2. Clean the hob.
3. Install the burner cap and make sure that it is seated correctly.
4. When installing the upper grill, pay attention to place the saucepan carrier so that the burner is centered.

### Glass ceramic surfaces

Wipe the glass ceramic surface using a piece of cloth dampened with cold water in a manner as not to leave any cleaning agent on it. Dry with a soft and dry cloth. Residues may cause damage on the glass ceramic surface when using the hob for the next time. Dried residues on the glass ceramic surface should under no circumstances be scraped with hook blades, steel wool or similar tools. Remove calcium stains (yellow stains) by a small amount of lime remover such as vinegar or lemon juice. You can also use suitable commercially available products. If the surface is heavily soiled, apply the cleaning agent on a sponge and wait until it is absorbed well. Then, clean the surface of the hob with a damp cloth.



Sugar-based foods such as thick cream and syrup must be cleaned promptly without waiting for the surface to cool down. Otherwise, glass ceramic surface may be damaged permanently.


Slight color fading may occur on coatings or other surfaces in time. This will not affect the operation of the product. Color fading and stains on the glass ceramic surface is a normal condition, and not a defect.

### Cleaning the control panel

Clean the control panel and knobs with a damp cloth and wipe them dry.



Do not remove the control buttons/knobs to clean the control panel. Control panel may get damaged!




- 1 Knob
- 2 Sealing element


### Gas Jet Cleaning Procedure

- Every six months the gas jets on your hob should be cleaned to ensure continued efficient and safe operation.
  - This may be done using a Gas Jet Cleaning Kit which may be purchased from your nearest Defy Service Centre.
  - The kit comprises of a sliding T-bar (A) a socket (B) and a 'Classic pin' (C).
  - **Fit the T-bar to the socket and remove the pot stand, burner cap and burner body.**
1. Insert the socket into the central tube of the burner so that it locates over the brass gas jet at the bottom of the tube.
  2. Gently loosen the brass gas jet by turning the socket in an anti-clockwise direction.
  3. Carefully lift the socket and loosened brass gas jet from the central burner tube.
  4. Insert the Classic pin into central hole of the jet and slide it up and down until the jet is free of accumulated dirt.
  5. Re-assemble in reverse order.
  6. Clean all the burner jet in the manner described above.


#### JET CLEANING KIT




1




2



3



4



## 7 Troubleshooting

### Problem solving guide—before calling for technical support

<b><i>There is no gas:</i></b>	
Main gas valve is closed.	<i>Open gas valve.</i>
Gas pipe is bent.	<i>Ensure the gas pipe has been properly fitted.</i>
<b><i>There is no ignition spark:</i></b>	
No current.	<i>Check fuses in the fuse box.</i>
<b><i>Burner is not burning properly or not at all:</i></b>	
Burner is dirty.	<i>Clean burner components.</i>
Burner is wet.	<i>Dry the burner components.</i>
Burner cap is not fitted correctly.	<i>Mount the burner cap correctly.</i>
Gas valve is closed.	<i>Open gas valve.</i>
Gas cylinder is empty (when using LPG).	<i>Replace gas cylinder.</i>
<b><i>The burner will not light:</i></b>	
The gas pipe is twisted, bent or kinked.	<i>Ensure the gas pipe has been properly fitted.</i>
The burner is dirty or wet.	<i>Clean / dry the burner components.</i>
The gas cylinder is empty.	<i>Replace gas cylinder.</i>
The burner cap is not fitted correctly.	<i>Fit burner cap correctly.</i>
The gas pressure regulator is closed.	<i>Check to see if the regulator is open.</i>
The lighting procedure has not been followed correctly.	<i>Follow the correct lighting procedure.</i>
<b><i>The flame is yellow Pots and pans are stained:</i></b>	
The burner is dirty or wet.	<i>Clean / dry the burner components.</i>
The gas is running out.	<i>Replace gas cylinder.</i>
The burner cap is not fitted properly.	<i>Fit burner cap properly.</i>
The gas pipe is twisted, bent or kinked.	<i>Ensure the gas pipe has been properly fitted.</i>
<b><i>Smell of leaking gas:</i></b>	
Are all the control knobs in the off position?	<i>Check to see the knobs are in the off position.</i>
The gas pipe is fitted incorrectly.	<i>Ensure the gas pipe has been properly fitted.</i>
The hose clamps require tightening or replacing.	<i>Have hose clamps tightened or replaced.</i>
The regulator is faulty and needs to be replaced.	<i>Have regulator checked and replaced.</i>



If the problem cannot be remedied after following the troubleshooting problem solving guide, please consult with an authorised service agent or the dealer where you purchased the appliance. Never attempt to repair a defective appliance yourself.

## 8 Defy customer care call centre

If you have followed the instructions and still have a problem or have any service or spares queries, please contact the customer care line by sending an email to [service@defy.co.za](mailto:service@defy.co.za) or by calling 0861 00 3339. They will be able to advise you on any aspect of the appliance.

---

### Defy Sub-Saharan Africa Branch contact details

#### **ZAMBIA: SOUTHGATE INVESTMENTS LTD**

Plot 1606, Sheki Sheki Road  
P.O. Box 33681  
Lusaka, 10101, Zambia  
Tel: +260 0211 242332/3  
Fax: +260 0211 242933  
[defyservicecenter@outlook.com](mailto:defyservicecenter@outlook.com)

#### **NAMIBIA: ATLANTIC DISTRIBUTORS (PTY) LTD**

10 Tienie Louw Street, Northern Industrial Area  
P.O. Box 21158, Windhoek, Namibia  
Tel: (061) 216162  
Fax: (061) 216134  
[atlantic@mweb.com.na](mailto:atlantic@mweb.com.na)

#### **ZIMBABWE: TRADE COM AFRICA**

Trade Com Africa, 183 Loreley Crescent  
Msasa, Harare, Zimbabwe  
Tel: +00263 773 438001  
[servicecentre@tradecomafrika.com](mailto:servicecentre@tradecomafrika.com)

#### **BOTSWANA: RAY MORGAN AGENCIES**

RMA Service Centre, Plot 48, East Gate  
Gaborone International Commerce Park  
Kgale View, Gaborone  
Botswana  
Tel: +267 390 3996 / 390 3912  
Fax: +267 318 7376  
Cell: +267 7134 6539  
[service@rma.co.bw](mailto:service@rma.co.bw)

#### **SWAZILAND: LYNDS DISTRIBUTORS**

P.O Box 716, Mbabane, Swaziland, H100  
Tel: (00268) 2515 4310/8  
Fax: (00268) 2518 4318  
[workshop@hoageys.co.sz](mailto:workshop@hoageys.co.sz)

#### **MOZAMBIQUE: COOL WORLD. LDA**

Rua da Resistencia No. 97B R/C  
Cell: +258 84 44 61 234  
[mdwholesale@mweb.co.za](mailto:mdwholesale@mweb.co.za)  
Nosso Show Room  
Av: da Industrias, Parcela No.735 \* 735A  
Machava, Maputo

## 9) Installer's details to be recorded below

### **INSTALLER'S NAME AND**

**COMPANY**.....

.....

.....

### **INSTALLER'S REGISTRATION**

**NUMBER**.....

.....

**HAVE YOU RECEIVED A WRITTEN COMPLETION  
CERTIFICATE?**

.....

**HAS THE INSTALLER EXPLAINED THE  
OPERATIONAL DETAILS OF YOUR STOVE TO  
YOU?**.....

## 10 Warranty

This certificate is issued by DEFY APPLIANCES (PTY) LTD manufacturers of Defy and Ocean products, hereinafter the Company, to the original purchaser only, of the appliance described on the certificate and shall constitute the only warranty given in respect of this appliance.

The Company warrants to the original purchaser that for a period of TWO YEARS from date of purchase the appliance is free from defect under normal domestic use, both in workmanship and material, subject to the following conditions.

1. Repair or replacement of any part of this appliance, found by the Company to be defective, shall be at the election of the Company. The Company reserves the right to effect such service through any of its Service Divisions or Authorised Service Dealers. The cost of such service shall be borne by the Company in full, provided that the appliance is located no further than 50 km from a Company Service Centre or an Authorised Service Dealer. Where the appliance is located beyond the 50 km radius, the purchaser shall be liable for the standard travelling charges, as determined by the Company.  
CARRY IN SERVICE Microwave ovens, Compact cookers and small appliances are repaired in our service centres and are not collected from the customers home. Faulty units should be delivered to the purchasing dealer or to the nearest Company Service Centre for warranty repairs.
2. Cracked, rusted or corroded solid plates, vitreous enamelware, rust, cosmetic wear or cosmetic/external damage to products/components/fuses and lamps are specifically excluded from these warranties. It is an express condition of these warranties that the purchaser takes due care and attention in the use and maintenance of the appliance. Abuse, misuse in conflict with operating instructions, connection to incorrect voltages and subjection to commercial use shall release the Company from its obligations.
3. This warranty shall become void and cease to operate if the appliance is dismantled by, or any repairs to the appliance are effected by any persons not duly authorised by the Company, or if substitute parts not approved by the Company are used in the appliance, or if the serial number of the appliance is removed.
4. The Company shall not be responsible for damages resulting from fire, flood, civil disturbances or any Act of God. The Company shall not, in terms of these warranties be responsible nor held liable for any consequential loss or damage of any kind caused by or due to the failure or malfunction of the appliance. The Company shall not be responsible for damages caused by insect and/or animal infestation.
5. The Company shall not be responsible for transportation or other costs other than those incurred within the provisions of Point 1 of this Certificate.
6. **For warranties in the Republic of South Africa and Sub-Saharan Africa, please contact the customer care line. Please refer to the previous page for South African and Sub-Saharan African contact details.**
7. Where service is requested under warranty and no fault or defect can be found by the Company, all costs incurred will be for the purchaser's account.
8. This Certificate as well as your invoice will serve as proof of purchase. For the purpose of warranty, it will be essential to produce this Certificate and invoice. Failure to do so, will render the purchaser liable for service costs.

**KEEP THIS CERTIFICATE AND SALES INVOICE AS PROOF OF PURCHASE FOR WARRANTY PURPOSES.**